



## JVJ USB Flash Drive

**X Series** (X5/X6/X9/X22)  
**M Series** (M4/M5/M6/M8)

### Quick Start Guide 快速入门指南



08/2003

#### Minimum System Requirements:

- Windows 2000, XP
- Windows 2000, Macintosh OS 10 and Linux (Storage only)\*\*
- USB 2.0 port required for high-speed data transfer

#### INSTALLING

- Windows 2000, XP
- Macintosh OS 10
- Linux

No additional driver installation is required. Plug the USB Flash Drive into the USB port on your computer to use.

#### DISCONNECTING

You don't need to shut down your computer to disconnect the USB Flash Drive, but to avoid losing data you should never remove the device from the USB port while the LED is flashing. If a drive window is open, close any associated windows before attempting to remove your USB Flash Drive.

#### Windows

These steps are not required for Windows XP.

Use the "Safe to Remove Hardware" hotplug icon in the notification area of the taskbar to safely remove the device before unplugging. The notification area is to the right of the taskbar where you usually see the current time displayed.

1. In the notification area, right-click on the "safe to remove hardware" hotplug icon.
2. Select the device you want to unplug, and then click Stop.
3. When Windows notifies you that it is safe to do so, unplug the USB Flash Drive from your computer.

#### Macintosh

1. Drag the removable disk to the desktop Trash icon.
  2. Unplug your USB Flash Drive.
- (Note: LED may stay illuminated)

#### Disposal Instructions

Do not dispose of this device with unsorted household waste. Improper disposal may be harmful to the environment and human health. Please refer to your local waste authority for information on return and collection systems in your area.

#### 最低系统需求:

- Windows 2000, XP
- Windows 2000, Macintosh OS 10+ 及 Linux (仅限储存)\*\*
- 高速数据传输所需的 USB 2.0 端口

#### 安装

- Windows 2000, XP
- Macintosh OS 10
- Linux

无需安装额外的驱动程序。将 USB 闪存盘插入您计算机的 USB 端口即可使用。

#### 断开连接

断开 USB 闪存盘的连接时无需关闭计算机，但是为了避免丢失数据，请切勿在指示灯正在闪烁时从 USB 端口拔出设备。如果驱动器窗口处于打开状态，请在尝试拔出 USB 闪存盘之前先关闭任何相关窗口。

#### Windows

Windows XP 操作系统无需这些步骤。

在拔出设备之前，请先使用任务栏通知区域中的“安全删除硬件”（Safe to Remove Hardware）热插拔图标安全地移除设备。通知区域位于您通常看到显示当前时间的任务栏右侧。

1. 在通知区域，右键单击“安全删除硬件”热插拔图标。
2. 选择要拔出的设备，然后单击“停止”（Stop）。
3. 当 Windows 通知您可以安全移除设备时，请从计算机上拔出 USB 闪存盘。

#### Macintosh

1. 将可移动磁盘拖至桌面的“Trash”图标。
  2. 拔出 USB 闪存盘。
- (请注意：指示灯可能保持恒亮)

#### 处置说明

请勿将此设备与未分类的生活垃圾一起处置。处置不当可能会危害环境和人体健康。请咨询您当地的废弃物管理机构，以了解本地废弃物回收和收集系统的相关信息